

Termites don't keep banker's hours. They chew quietly, out of sight, until one day a baseboard caves under your thumb or a door header sags enough that the latch no longer lines up. When the damage finally shows itself, you want a trustworthy, on-call wood repair contractor who can stabilize the structure, coordinate with pest control, and restore [termite exterminator](#) the house without drama. I've spent enough weekends under crawlspaces and inside sweltering attics to know what matters when your home's frame is involved. This is a field guide to acting fast, hiring well, and getting durable repairs that look and perform like the original build.

What “on-call” really means for termite wood repair

In practice, an on-call contractor for termite damage is someone who answers the phone after hours, can triage within a day, and has the tools to shore a structure on the first visit. That first trip might not include final cosmetic repairs. The priority is to make the home safe, stop further damage, and map the structural termite repair plan. Think bottle jacks and cribbing in a crawlspace, not new crown molding.

For homes with active infestations, the contractor often coordinates with a pest professional. Termite repair services should never trap active colonies inside new wood. The right sequence is assess, stabilize, treat, verify, then rebuild. A contractor who pushes straight to finish work without asking for proof of treatment is doing you a disservice.

How damage hides in plain sight

Subterranean termites typically come from the soil, travel through mud tubes, and prefer moist, concealed routes. Drywood termites colonize the wood itself, often in attics or upper stories. Either way, the telltale clues are subtle until the damage is extensive. I've seen sill plates that looked fine from the outside but crumbled like cornflakes once the siding was pried back. I've also seen floor joists that had been hollowed from the inside, leaving a deceptively sound skin.

If you're looking up “termite repair near me” because the floor bounces or a corner of the house feels spongy, assume there's more going on than what you can see. Termite framing repair is almost always bigger than the first measurement. Plan your time and budget with that in mind, and choose a wood repair contractor for termite damage near me who is clear about contingencies.

First-hour actions that actually help

- Take clear photos and short videos of the damage and any mud tubes, frass, or blistered paint.
- Avoid tearing out finishes unless a safety issue demands it. Disturbing galleries can scatter live termites.
- If a floor or header feels unsafe, restrict access to that area and reduce loads above it.
- Kill water leaks immediately and set up basic ventilation or a fan to dry the area.
- Call a licensed pest control company and a local termite damage repair contractor the same day.

Those five moves keep you safe, preserve evidence, and accelerate insurance or warranty claims. They also help the contractor decide whether to arrive with light-duty shoring or heavier gear.

What a thorough assessment looks like

Good termite damage restoration starts with a crawl, not a guess. On a proper inspection, I carry a sharp awl, a moisture meter, and a strong light. I probe suspect members every few inches, not just at the ends, and I document with measurements. If I'm looking at termite sill plate repair, I'll pop a couple of siding fasteners to peek behind the rim. For termite floor joist repair, I'll check bearing points on the foundation, not just the midspan. And if we're discussing termite beam repair under a sagging living room, I'll measure deflection with a stringline and consult span tables before promising a band-aid.

Expect your contractor to map affected zones: sills and rim, joists, girders or beams, posts, subfloor, wall studs and plates, window and door headers, and roof framing. Termite attic wood repair often reveals itself after a roof leak or HVAC condensation issue, so humidity readings up there matter. Termite wall repair might mean sistering studs, but I've opened walls that needed a full king-jack rebuild at window openings. Ask the contractor to describe load paths in plain English. If they can't tell you how the weight transfers from roof to soil, they can't design a confident repair.

Stabilize, then treat, then restore

It's tempting to skip to new wood, but a proper sequence saves money and dust.

Stabilization comes first. Temporary posts, screw jacks, and cribbing relieve stress and prevent further cracking in finishes. On a recent job, a kitchen floor had dropped almost three quarters of an inch over a termite-weakened girder. We installed two temporary jack posts with 4x4 cribbing, nudged the floor up over two days, and locked it with a sistered LVL. The slow lift helped avoid popping a forest of tiles and seams.

Treatment comes next. Subterranean infestations usually call for soil trenching and termiticide or bait systems. Drywood infestations might require localized injections or whole-structure fumigation. The critical step is verification. I like to see a written report stating treatment date, method, and any guarantee. Only then does the permanent termite structural repair make sense.

Restoration is the craft part. It includes replacing or reinforcing damaged members, addressing moisture, insulating if needed, and finishing with subfloor, drywall, trim, and paint. If you're exploring termite drywall repair after termite treatment, remember that drywall is the easy piece. The structural wood behind it is the story.

Materials and methods that hold up

Most termite wood repair falls into three categories: replacement, reinforcement, or consolidation.

Replacement means removing compromised members and installing new ones. For termite sill plate repair, I often cut out sections between anchor bolts and slide in pressure-treated 2x lumber, using stainless or hot-dipped galvanized fasteners and sill seal to isolate from concrete. Where bolt patterns make it tricky, I'll drill new holes and epoxy-set anchors, then tie plates with metal connectors that match the original uplift requirements. In older homes with balloon framing, we may need to support the wall above, make a controlled cut, and rebuild the connection detail to modern standards.



Reinforcement, or sistering, is common for termite floor joist repair and termite beam repair. Sistering means adding a new joist or LVL alongside the old, glued and bolted at a proper spacing. Done right, the new member carries the load and the old one acts as a spacer. I avoid piecemeal scabbing unless the engineer signs off or the loads are truly light. For main beams, consider steel flitch plates or full LVL replacements if the footprint allows. Always reestablish bearing on solid points. A beautiful LVL means nothing if it sits on crumbling brick or a termite-riddled post.

Consolidation has its place in termite subfloor repair and some non-structural trim. Epoxy consolidants can harden punky wood around window sills or door casings, but I rarely rely on them for primary structure. On one 1920s bungalow, we used epoxy only to stabilize the bottom inch of a decorative beam after cutting back to sound wood and capping with a dutchman. The rest of the load traveled on a new LVL hidden behind the fascia.

Moisture control is part of every fix. For crawlspaces, I recommend a vapor barrier, proper grading so water runs away from the foundation, and vents or a sealed, conditioned crawl depending on climate. For attics, repair baffles, check bath fan terminations, and insulate properly to avoid condensation. Termite damage repair that ignores moisture is a revolving door.

How long does it take, and what does it cost

Timelines vary by scope and scheduling. Emergency stabilization is often same day or next day. Full termite damage restoration can run a few days for localized sill plate or subfloor sections, up to several weeks when beams, kitchens, or baths are involved.

Costs swing with markets and access. I've repaired small sections of termite wall framing for a few hundred dollars in labor and materials when we opened a panel for another reason. More common ranges for stand-alone projects look like this: a modest termite sill plate repair along one short wall might land in the low thousands; a multi-joist termite floor joist repair with new piers or a beam often runs mid to high thousands; a whole house with widespread termite structural repair can climb into the tens of thousands, especially if we're coordinating with fumigation, engineering, and finish restoration. If a contractor quotes a single flat fee without seeing the job, be cautious. Real estimates detail line items and allowances for hidden damage.

Inside a typical repair sequence

Let me walk through a real pattern. A homeowner noticed baseboards bowing in a dining room. Moisture readings were high along the exterior wall, and the crawlspace revealed mud tubes, a chewed sill plate, and two

compromised joists. We set two temporary posts under the joist ends. Pest control treated the perimeter trench and spot-treated in the crawl. After a three-day window to let the soil settle and confirm no live activity, we returned, lifted the floor an eighth of an inch at a time, and cut out a 10-foot section of the sill. We slid in new pressure-treated lumber, epoxy-set two new anchor bolts, added strap ties to the rim, and sistered both damaged joists with full-length LVLs that extended onto sound bearing. Subfloor sections with delamination were replaced. Inside, we patched drywall, primed with a stain blocker, and reinstalled baseboards with a back-bevel to accommodate a slightly out-of-plumb wall, a common fix in older homes. From first call to final paint, the project took two weeks with three active workdays.

When you need an engineer

Not every termite damage repair needs stamped drawings, but some do. If you see significant beam deflection, concentrated loads, or masonry cracks that follow a stepped pattern across multiple courses, bring in a structural engineer. I typically call for engineering when replacing main girders, modifying load-bearing walls, or when we need to reconfigure headers for large openings. An engineer adds cost upfront, but they often save money by allowing cleaner, code-compliant solutions that pass inspection the first time.

Permits, inspections, and insurance

Many jurisdictions require permits for structural termite repair. Sill plates, beams, and headers are not cosmetic. A good contractor knows the local process, pulls the permit, and meets the inspector with photos of the concealed conditions. On renovation projects, I've had inspectors approve closed-up work because the documentation was thorough and the repair logic sound.

Homeowners insurance coverage varies. Active infestation treatment is usually excluded, but consequential damage from hidden wood-destroying insects can be covered in some policies. If you're filing a claim, document before, during, and after. Keep the pest report, the repair estimate that explicitly states termite damage repair, and invoices for materials and labor. If your house has a termite bond or warranty, notify the provider before you touch anything structural, or you could void coverage.

Wall, floor, and attic specifics

Termite wall repair involves more than swapping a stud. Load-bearing walls need their kings, jacks, and headers to work as a team. If a window header has been hollowed, I'll support the opening with a temporary wall, remove the trim and sheathing as needed, then replace the header with an [licensed Vanguard termite inspectors Watsonville](#) LVL or engineered lumber to match span and load. I'll also check for nibbled sheathing at the bottom plate, commonly missed.

Termite subfloor repair depends on the extent of delamination and the floor covering above. Under tile, I like to remove and replace full sheets rather than patching corners, then reinstall a proper underlayment. Under hardwood, I'll stagger seams and glue-screw for squeak control. For carpeted rooms, patching is simpler, but I still align to joist centers and block edges to avoid soft spots.

Termite attic wood repair often means sistering rafters and reinforcing ridge connections. If ventilation was poor, I add baffles and make sure bath fans vent outdoors, not into the attic. I've pulled more than one soffit to find a flexible duct pointed at insulation, exactly the kind of moisture source termites appreciate.

Drywall repair after termite treatment that blends in

Once the structure is solid and treated, drywall work should be routine. The trick is blending patches with existing textures and lines. I prefer to feather joints wider than you think you need, especially under side lighting where shadows exaggerate any ridge. Prime the entire wall if stains bled through, and paint corner to corner to avoid flashing. If you're selling soon, this final pass makes as much difference as the structural work in terms of buyer confidence.

Finding the right local pro

Searching for termite damage repair near me brings up a mix of general contractors, handypeople, and specialists. The label matters less than verifiable experience with wood framing and coordination with pest control. Ask for jobs that involved termite beam repair or structural termite repair near me, not just trim replacement. A contractor who has photos of shoring, sistered members, and rebuilt sills will almost always outperform someone whose portfolio is all kitchens and paint.

Expect the contractor to discuss access. Crawlspace with less than 18 inches of clearance change the game. So do utilities routed through joists. On a nasty crawl, I'll sometimes propose a small excavation for safer work or run new cable routes to clean up spaghetti that made termites' path even easier.

Five questions worth asking before you hire

- How will you stabilize the structure before opening walls or pulling joists?
- Do you coordinate with pest control and wait for written proof of treatment?
- What's your typical approach for sill plate, joist, and beam repairs, and do you have photos of similar jobs?
- Will you pull permits if required, and how do you document concealed work for inspectors and insurers?
- What contingencies do you include for hidden damage, and how do you price changes fairly?

You'll notice none of these questions mention price first. Cost matters, but the cheapest bid that ignores shoring, treatment verification, or permitting will cost more by the end.

The "near me" factor and why it helps

There's real value in hiring local termite damage contractor near me. Local pros know soil conditions, common framing methods in your neighborhood, and which inspectors want to see what. In coastal regions with higher humidity, I lean harder on borate-treated lumber for non-ground-contact spots. In arid climates with drywood termites, I expect more attic work and more attention to soffit and fascia transitions. A local who's repaired three houses on your block will rebuild yours faster and with fewer surprises.

Work quality tells you what you can't see

When you tour finished work, look for tells. Are the new joists fastened with proper nails or structural screws, not drywall screws? Are metal connectors the right type, properly filled with fasteners, not half empty? Are cuts clean, and is lumber crowned consistently? Do posts sit on concrete with a proper base and moisture break, not dirt? Is the new subfloor glued and screwed, edges blocked, and seams tight? The visible details reflect the care behind the walls.

Edge cases I see a lot

Additions that married a slab-on-grade family room to a crawlspace main house often develop hidden termite highways at the transition. The repair calls for attention to the mudsill at the step, weep screeds if stucco is involved, and sealing gaps in the rim area. Another edge case is fireplace chases framed from wood with minimal clearances. Termites love the warm, protected void. Repair here might involve partial demo and reframing plus a fresh termite treatment barrier around the hearth footing.

Metal framing in basements is not immune either. I've opened basements to find treated bottom tracks but untreated wood blocking bridging to the slab, exactly where subterranean termites entered. Even if you don't see galleries in the steel, they feast on the nearest wood component. The fix involves removing food sources and establishing a continuous barrier.

How preventive steps pay for themselves

Once the dust settles, put the house on a maintenance rhythm. Schedule annual termite inspections, even if your warranty says every two years. Re-grade soil that has crept up above the foundation line. Keep a 6 to 8 inch clearance from soil to siding. Add downspout extensions and fix splashback that wets the sill. In vented crawlspaces, make sure insulation isn't drooping against the subfloor, trapping moisture. In sealed crawls, check dehumidifier drains and filters. In attics, confirm that vents are open and baffles aren't crushed by insulation. These details extend the life of your termite damage repair and reduce the chance you'll be searching for local termite damage repair again next spring.

Coordinating schedules without losing weeks

The longest delays usually happen between treatment and rebuild. I work with pest companies to set expectations: trenching today, verification in 24 to 72 hours, then structural work. For fumigations, we schedule demo or reinforcement right after the house is cleared for reentry. If your contractor can't articulate a plan that threads these pieces together, you'll wait longer than you need to.

Inside the house, choose finishes that keep the timeline lean. If you're on a tight budget, saving original trim where possible and repainting entire surfaces rather than color matching small patches can keep labor manageable. A contractor who gives you options here demonstrates they've walked this road.

What success looks like

On a good project, you'll see a clean sequence, minimal surprises, and clear documentation. The floor feels solid again. Doors close without force. Cracks from sagging stop growing. The pest report sits in a folder with your permits and photos. And the house, newly sound, fades back into the background of your life where it belongs.

If you're staring at chewed timber, searching for termite damage repair near me, don't panic. Act quickly, but choose deliberately. Look for a team that can shore at once, works hand in glove with treatment pros, and knows how to rebuild load paths with the right materials. Whether it's termite wall repair behind a powder room, termite subfloor repair under the laundry, or a gnarly termite beam repair in the crawl, the right approach is systematic and calm. Done well, repair termite damage to house structures doesn't just restore strength, it also teaches you how your home works and how to keep it that way.

And if you catch the problem early, your fixes stay small. I've replaced a single stud and a foot of sill, primed and painted in a day, and wished every call went that way. I've also replaced a forty-foot beam and rebuilt half a kitchen after years of quiet chewing. Both jobs ended with a sturdy house and a relieved owner. The difference was timing and a crew that knew exactly what to do when they picked up the phone.